

Användning av FlexLOCK

Vid leverans

1. Öppna dörren och dra bort plastflärpen för att aktivera låset. Motorn ger ifrån sig ett ljud.

Lägg till användare

1. För programmeringskortet över låset. Upprepande toner hörs.
2. För användarens kort/tagg över låset inom 7 sek. Bekräftelseton hörs.
3. Nu är användaren inlagd.
4. Repetera denna procedur tills alla användare som ska kunna använda låset är inlagda.

Mifare – Maximalt kan 200 användare + servicekort läggas till per lås.

EM – Maximalt kan 45 användare + servicekort läggas till per lås.

Ta bort användare

1. För programmeringskortet över låset. Upprepande toner hörs.
2. För användarens kort/tagg över låset inom 7 sek. Bekräftelseton hörs.
3. Nu är användaren borttagen.

Användning

1. För att öppna håller man sitt användarkort/tagg centrerat över låset.
2. Låset öppnar sig.
3. Stäng dörren helt och låset låser sig automatiskt.

Håller man ett ej godkänt kort/tagg över låset hörs fyra korta toner.

När batteriet börjar ta slut hörs upprepande dubbla långa toner från låset.

Use of FlexLOCK

By delivery

1. Open the door and pull away the plastic pin to activate the lock..
The engine makes a sound.

Add user

- 1 Slide the programming card over the lock. Repetitive tones are heard.
- 2 Slide the user's card/tag over the lock within 7 sec. Confirmation tone is heard.
- 3 Now the user is logged in.
- 4 Repeat this procedure until all users who will be able to use the lock are entered.

Mifare – A maximum of 200 users + service cards can be added per lock.

EM – A maximum of 45 users + service card can be added per lock.

Delete user

- 1 Slide the programming card over the lock. Repetitive tones are heard.
- 2 Slide the user's card/tag over the lock within 7 sec. Confirmation tone is heard.
- 3 The user is now deleted.

Use

- 1 To open, you hold your user card/tag centered over the lock.
2. The lock opens.
3. Close the door completely and the lock will lock automatically.

If you hold an unapproved card/tag over the lock, four short tones are heard.

When the battery starts to run out, repeated double long tones are heard from the lock.